SALECNC.net

คู่มือการใช้งานเครื่องเสียบไม้มื้ออัตโนมัติ

AUTOMATIC MEAT SKEWER MACHINE • QUICK START



1 ต่อสายลมและตั้งแรงดัน
Connect air and set pressure

ใช้สายลมขนาด 8 มม.
Use an 8 mm air hose.



0.2 MPa = 2 bar ≈ 2.04 kgf/cm²

2 เรียงเนื้อในถาด
Arrange meat in the tray



วางเนื้อให้เรียบร้อยในแต่ละช่อง
Place meat neatly in each compartment.

3 ใส่ไม้เสียบในช่องป้อนไม้
Load skewers into the feeder



ไม้ยาว 150 มม. เส้นผ่านศูนย์กลาง 2.5–3 มม.
Skewer length: 150 mm • Diameter: 2.5–3 mm

เรียงไม้ให้หันไปทางเดียวกัน
Align all skewers in the same direction.

4 วางถาดบนสายพาน
Place the tray on the conveyor



จัดถาดให้ตรง และให้เนื้ออยู่ต่ำกว่าขอบถาด
เพื่อไม่ให้กีดขวางแนวไม้เสียบ
Align the tray. Keep meat below the tray rim
so it does not obstruct the skewers.

5 เปิดเครื่องเพื่อเริ่มเสียบไม้
Switch on to start skewering



ห้ามสอดมือเข้าใกล้ส่วนที่เคลื่อนที่ขณะเครื่องทำงาน
Keep hands clear of moving parts while the machine is running.

SALECNC.net

AUTOMATIC MEAT SKEWER MACHINE • QUICK START



1 Connect air and set pressure

Use an 8 mm air hose.



0.2 MPa = 2 bar ≈ 2.04 kgf/cm²

2 Arrange meat in the tray



Place meat neatly in each compartment.

3 Load skewers into the feeder



Skewer length: 150 mm • Diameter: 2.5–3 mm

Align all skewers in the same direction.

4 Place the tray on the conveyor



Align the tray. Keep meat below the tray rim so it does not obstruct the skewers.

5 Switch on to start skewering



Keep hands clear of moving parts while the machine is running.